

## Racores neumáticos DE USO INDUSTRIAL

### KQ2H

#### Racor macho

Rosca BSPT

Código	Diámetro del tubo	Tamaño de rosca
KQ2H04-M5A	Ø4	M5x0.8
KQ2H04-01AS		1/8"
KQ2H04-02AS		1/4"
KQ2H06-M5A	Ø6	M5x0.8
KQ2H06-01AS		1/8"
KQ2H06-02AS		1/4"
KQ2H06-03AS	3/8"	
KQ2H06-04AS	1/2"	
KQ2H08-01AS	Ø8	1/8"
KQ2H08-02AS		1/4"
KQ2H08-03AS		3/8"
KQ2H08-04AS	1/2"	
KQ2H10-01AS	Ø10	1/8"
KQ2H10-02AS		1/4"
KQ2H10-03AS		3/8"
KQ2H10-04AS	1/2"	
KQ2H12-02AS	Ø12	1/4"
KQ2H12-03AS		3/8"
KQ2H12-04AS		1/2"
KQ2H16-03AS	Ø16	3/8"

### KQ2L

#### Racor codo 90° macho

Rosca BSPT

Código	Diámetro del tubo	Tamaño de rosca
KQ2L04-M5A	Ø4	M5x0.8
KQ2L04-01AS		1/8"
KQ2L04-02AS		1/4"
KQ2L04-03AS	3/8"	
KQ2L06-M5A	Ø6	M5x0.8
KQ2L06-01AS		1/8"
KQ2L06-02AS		1/4"
KQ2L06-03AS	3/8"	
KQ2L08-01AS	Ø8	1/8"
KQ2L08-02AS		1/4"
KQ2L08-03AS		3/8"
KQ2L08-04AS	1/2"	
KQ2L10-01AS	Ø10	1/8"
KQ2L10-02AS		1/4"
KQ2L10-03AS		3/8"
KQ2L10-04AS	1/2"	
KQ2L12-02AS	Ø12	1/4"
KQ2L12-03AS		3/8"
KQ2L12-04AS		1/2"
KQ2L16-04AS	Ø16	1/2"

### KQ2F

#### Racor hembra

Rosca BSPP

Código	Diámetro del tubo	Tamaño de rosca
KQ2F06-M5A	Ø6	1/8"
KQ2F06-01A		1/4"
KQ2F08-01A		1/8"
KQ2F08-02A	Ø8	1/4"
KQ2F10-02A	Ø10	1/4"
KQ2F12-03A	Ø12	3/8"

### KQ2E

#### Union pasa muro

Código	Diámetro del tubo
KQ2E04-00A	Ø4
KQ2E06-00A	Ø6
KQ2E08-00A	Ø8
KQ2E10-00A	Ø10

### KQ2V

#### Racor codo banjo

Rosca BSPT

Código	Diámetro del tubo	Tamaño de rosca
KQ2V06-01AS	Ø6	1/8"
KQ2V06-02AS		1/4"
KQ2V06-03AS		3/8"
KQ2V08-01AS	Ø8	1/8"
KQ2V08-02AS		1/4"
KQ2V08-03AS		3/8"
KQ2V10-02AS	Ø10	1/4"
KQ2V10-03AS		3/8"

### KQ2T

#### Racor tee macho al centro

Rosca BSPT

Código	Diámetro del tubo	Tamaño de rosca
KQ2T06-01AS	Ø6	1/8"
KQ2T06-02AS		1/4"
KQ2T08-01AS	Ø8	1/8"
KQ2T08-02AS		1/4"
KQ2T10-02AS	Ø10	1/4"
KQ2T10-03AS		3/8"
KQ2T10-04AS	Ø10	1/2"
KQ2T12-02AS	Ø12	1/4"
KQ2T12-04AS		1/2"

**KQ2U****Racor "Y" macho giratorio****Rosca BSPT**


Código	Diámetro del tubo	Tamaño de rosca
KQ2U06-01AS	Ø6	1/8"
KQ2U06-02AS		1/4"
KQ2U08-02AS	Ø8	1/4"
KQ2U08-03AS		3/8"
KQ2U10-02AS	Ø10	1/4"

**KQ2H****Unión**

Código	Tubo A	Tubo B
KQ2H04-00A		Ø4
KQ2H06-00A		Ø6
KQ2H08-00A		Ø8
KQ2H10-00A		Ø10
KQ2H12-00A		Ø12
KQ2H16-00A		Ø16
KQ2H04-06A	Ø4	Ø6
KQ2H06-08A	Ø6	Ø8
KQ2H06-10A		Ø10
KQ2H08-10A	Ø8	Ø10
KQ2H08-12A		Ø12
KQ2H10-12A	Ø10	Ø12
KQ2H12-16A	Ø12	Ø16

**KQ2L****Codo unión**

Código	Tubo A	Tubo B
KQ2L04-00A		Ø4
KQ2L06-00A		Ø6
KQ2L08-00A		Ø8
KQ2L10-00A		Ø10
KQ2L12-00A		Ø12
KQ2L16-00A		Ø16
KQ2L10-08A	Ø10	Ø8

**KQ2R****Reductor enclavable**


Código	Tubo A	Tubo B
KQ2R04-06A	Ø4	Ø6
KQ2R04-08A		Ø8
KQ2R06-08A	Ø6	Ø8
KQ2R06-10A		Ø10
KQ2R08-10A	Ø8	Ø10
KQ2R08-12A		Ø12
KQ2R10-12A	Ø10	Ø12

**KQ2U****Unión en "Y"**

Código	Tubo A	Tubo B
KQ2U04-00A		Ø4
KQ2U06-00A		Ø6
KQ2U08-00A		Ø8
KQ2U10-00A		Ø10
KQ2U12-00A		Ø12
KQ2U04-06A	Ø4	Ø6
KQ2U06-08A	Ø6	Ø8
KQ2U08-10A	Ø8	Ø10

**KQ2T****Tee unión**

Código	Tubo A	Tubo B
KQ2T04-00A		Ø4
KQ2T06-00A		Ø6
KQ2T08-00A		Ø8
KQ2T10-00A		Ø10
KQ2T12-00A		Ø12
KQ2T16-00A		Ø16
KQ2T04-06A	Ø4	Ø6
KQ2T06-08A	Ø6	Ø8
KQ2T08-06A	Ø8	Ø6
KQ2T08-10A	Ø8	Ø10
KQ2T10-08A	Ø10	Ø8
KQ2T16-12A	Ø16	Ø12


**KQ2U****"Y" enclavable**

Código	Tubo A	Tubo B
KQ2U06-99A		Ø6
KQ2U08-99A		Ø8
KQ2U10-99A		Ø10

**KQ2L****Codo 90° enclavable**

Código	Tubo A	Tubo B
KQ2L06-99A		Ø6
KQ2L08-99A		Ø8
KQ2L10-99A		Ø10





### KQ2TW

## Cruz unión

Código	Tubo A	Tubo B
KQ2TW04-00A	Ø4	
KQ2TW06-00A	Ø6	



### KQ2Y

## Codo regulador

Rosca BSPT

Código	Diámetro del tubo	Tamaño de rosca
AS1201F-M5-04	Ø4	M5x0.8
AS2201F-01-04S		1/8"
AS2201F-02-04S		1/4"
AS1201F-M5-06	Ø6	M5x0.8
AS2201F-01-06S		1/8"
AS2201F-02-06S		1/4"
AS2201F-01-08S	Ø8	1/8"
AS2201F-02-08S		1/4"
AS3201F-03-08S		3/8"
AS2201F-02-10S	Ø10	1/4"
AS3201F-03-10S		3/8"
AS4201F-04-10S		1/2"
AS4201F-04-12S	Ø12	1/2"

### VTPU

## Tubing

Código	Diámetro exterior	Diámetro interior	Color
VTPU-B-04	Ø4	Ø2.5	Azul
VTPU-T-04			Transparente
VTPU-B-06	Ø6	Ø4	Azul
VTPU-T-06			Transparente
VTPU-B-08	Ø8	Ø5	Azul
VTPU-T-08			Transparente
VTPU-B-10	Ø10	Ø6.5	Azul
VTPU-T-10			Transparente
VTPU-B-12	Ø12	Ø8	Azul
VTPU-T-12			Transparente



# Confía en Valiton, conecta con lo mejor.

CÓDIGO: CAT-VAL-05 REVISIÓN:00

